

Adjusting NCE Blinds

Step 1—Open Vertical Rail (Frame)



Step 2—Open fully both Blind and Flyscreen to locate fastening . Use Hex or Allen Key for adjustment



Step 3—Push fastener up to tighten



Step 4—Tighten LH & RH fastener evenly



Do not overtighten fastener, this may cause blind and flyscreen to become difficult to open and close and could cause damage to guide strings