

## DOWNLOADING GOOGLE CHROME


THANK YOU FOR PURCHASING AN NCE SMART TV WITH BLUETOOTH

Your NCE Smart TV with Bluetooth comes preloaded with Android Apps and Internet Browser settings. Some apps may require operating systems that may not be compatible with the default settings or may require a change to the internet platform.

In this instance, NCE recommends that the user installs GOOGLE CHROME as your internet browser setting.



To install Google Chrome –

1. Turn on your Smart TV and connect to your Internet / WiFi through the TV setting function




## DOWNLOADING GOOGLE CHROME


2. Open the default internet browser, or if you have a Google Account, open Google Playstore App on the Smart TV app page




3. Search for Google Chrome.




4. Select **INSTALL** in the downloads page of either your selected Browser or through Google Playstore



5. Open Google Chrome



6. Once opened, if requested, select YES to Google Chrome as your default browser



7. Log off Internet / WiFi connection, restart TV and then start and reconnect Internet / WiFi to your Smart TV as per normal.

If you experience any difficulties in installing Google Chrome, please check your internet connection and ensure you have a stable, strong connection. You may need to have the TV positioned in a strong frequency area or have LAN connection for the installation. You can also call NCE on 1300 366 024